



TRANSCCELL TECHNOLOGY, INC.



MODEL TI-500 SL

Digital Weight Indicator

User Manual

Revision 1.3 September 12, 2013

TABLE OF CONTENTS

Page

Contents

INTRODUCTION.....	1
FCC NOTE.....	1
INSTALLATION.....	2
PREPARATION.....	2
CONNECTIONS.....	2
CONNECTING THE WEIGH PLATFORM.....	3
CONNECTING THE SERIAL I/O DEVICE.....	4
CONNECTING THE POWER SUPPLY.....	4
CONFIGURATION.....	5
OVERVIEW.....	5
ACCESSING THE MENUS.....	5
MENU STRUCTURE.....	5
SETUP MENU DESCRIPTIONS.....	6
USER MENU DESCRIPTIONS.....	8
USER MENU PROCEDURES.....	10
EXITING THE MENUS.....	10
CALIBRATION.....	11
CALIBRATION OVERVIEW.....	11
ZERO CALIBRATION (F16).....	11
SPAN CALIBRATION (F17).....	11
VIEW CALIBRATION VALUES (F18).....	12
KEY-IN ZERO CALIBRATION VALUE (F19).....	12
KEY-IN SPAN CALIBRATION VALUE (F20).....	12
DISPLAY.....	13
KEYBOARD.....	13
FUNCTION KEYS.....	14
GENERAL SCALE OPERATION.....	14
WEIGHING AN ITEM.....	14
WEIGHING ANIMALS.....	14
RECHARGEABLE BATTERY INFORMATION.....	15
LEGAL FOR TRADE SEALING.....	16
APPENDIX A: SPECIFICATIONS.....	17
APPENDIX B: SERIAL PORT INFORMATION.....	18
SERIAL PORT MODES.....	18
DEMAND DUPLEX MODE.....	18
CONTINUOUS DUPLEX MODE.....	18
OUTPUT STRINGS.....	19
TEXT PRINT TICKET.....	19
STRING FORMAT 1 (Condec Demand String).....	19
STRING FORMAT 2 (Condec Continuous String).....	19
APPENDIX C: DISPLAYED ERROR CODES.....	20

INTRODUCTION

The TI-500 SL Digital Indicator is a general purpose, industrial grade weight indicator. One model is currently available, distinguishable by display type, enclosure type and power supply. Table 1 shows the TI-500 SL product matrix.

This model can readout up to 50,000 display divisions and can supply enough current for up to 4-350Ω load cells. All setup parameters may be entered via the front panel keys, including calibration.

If your Model TI-500 SL Digital Indicator is part of a complete floor scale or has already been installed for you, you may skip to the operating instructions. Prior to using the indicator, please read this chapter carefully and completely. Store the manual in a safe and convenient place so it will be available if you have questions concerning the operation of the scale.

MODEL	DISPLAY TYPE	ENCLOSURE TYPE	POWER SOURCE
TI-500 SL	LCD	Stainless Steel	12 VDC AC adapter or internal 6V rechargeable battery

TABLE 1: TI-500 SL Product Matrix

FCC NOTE

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©Transcell Technology, Inc. 2008-2012. All rights reserved.

The information contained herein is the property of Transcell Technology and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorized by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.

Contents subject to change without notice.

975 Deerfield Parkway Buffalo Grove, IL 60089
Tel (847) 419-9180 Fax (847) 419-1515
<http://www.transcell.com>

INSTALLATION

PREPARATION

Any precision instrument requires a suitable environment in which to operate as intended. Please review each of the following prior to installation:

Electrical Power

The TI-500-SL indicator has been designed to operate from 10 to 12 VDC and ships with an AC adapter designed to operate from the local line voltage.

To avoid electrical noise interference and/or stray AC electrical transients, try to operate the indicator from a circuit separate from any equipment containing inductive devices such as a contactor coil, solenoid, relay coil, or motor. Be sure to use shielded cables for the load cell connections (ground shield wire at indicator) and run these cables away from your AC/DC power cables if possible.

In extreme cases, it may be necessary to install surge suppressors, line conditioners or even UPS (Uninterruptible Power Supplies) systems (not included).

Environment

- Avoid installing the indicator in areas of direct sunlight or high humidity
- Avoid sudden temperature change – if this is unavoidable allow equipment to ‘soak’ at a constant temperature for at least three hours before use
- Ensure that steady, clean AC power is available to the unit

Remember that the installer is ultimately responsible to assure that a particular installation will be and remain safe and operable under the specific conditions encountered.

CONNECTIONS

The rear cover must first be removed to make the appropriate connections to the weigh platform, printer and remote display.

Caution! Disconnect power source from indicator prior to removing rear cover.

Caution! A 6V rechargeable battery is attached to the inside of the rear cover; care must be taken when removing and installing the rear cover so as to avoid a shorting hazard.

To remove the rear cover,

1. Remove the ten [10] screws that secure it to the enclosure and gently pull it off of the enclosure
2. Remove the black lead from the negative (-) battery terminal first
3. Remove the red lead from the plus (+) battery terminal last
4. Unplug the CAL switch from the JP4 terminal on the main PCBA
5. Remove the rear cover completely and set aside on a non-metal work surface.

Caution! While the rear cover is off, do not allow the positive (+) and negative (-) battery terminals to be shorted.

Caution! Never open the fuse holder while the battery leads are connected to the battery. Remove both battery leads from the battery before opening the fuse holder.




Figure 1: TI-500 SL Main PCBA

CONNECTING THE WEIGH PLATFORM


Connect the shielded load cell cable or homerun cable (not included) from the weighing platform to the appropriate terminal on the main PCBA.

Load Cell Terminal (J5)

<u>Name</u>	<u>Function</u>	<u>Name</u>	<u>Function</u>
+EXC	+ Excitation	+SIG	+ Signal
+SEN	+ Sense	-SIG	- Signal
-EXC	- Excitation	GND	Shield
-SEN	- Sense		

NOTE: In default configuration; +SEN and –SEN connections are not required; however if you do need to connect these signals, be sure to remove the solder bridge on both JP5 and JP6 before doing so.

Now if you have an older unit, then these same connections would take place on terminal J1 instead – see diagram below for connections.



NOTE: E+ = + Excitation, S+ = + Signal, E- = - Excitation, S- = - Signal

CONNECTING THE SERIAL I/O DEVICE

The TI-500 SL indicator ships standard with one full duplex RS-232 serial port, designed for connection to a computer or a serial printer. This same port may be also used as a simplex, RS-232 port designed for connection to a remote display.

Connection assignments for all serial RS-232 communication terminals on the MTI-500-WB indicator are shown below.

RS-232 Communication Terminal (J3)

<u>Name</u>	<u>Function</u>	<u>Name</u>	<u>Function</u>
TXD	Transmit Data	DTR	Data Terminal Ready
RXD	Receive Data	DSR	Data Set Ready
GND	Signal Ground		

CONNECTING THE POWER SUPPLY

The indicator ships standard with an external AC to DC adapter which doubles as a battery charger. Simply plug the AC adapter into the indicator's DC Power Jack first, and then plug into a standard AC wall outlet. ***Make sure that the AC voltage appearing at the wall outlet matches the input voltage marked on the AC adapter.***

Now if you wish to make a repair, then these power connections would take place on terminal J2 of the main PCBA – see diagram below for connections.

DC Power Connection Terminal (J2)

<u>Name</u>	<u>Function</u>
P+	Plus (+)
P-	Minus (-)

NOTE: 12 to 15 VDC is typically applied to this indicator as about 6.9 VDC is required to re-charge the battery.

CONFIGURATION

OVERVIEW

The indicator contains two main configuration menus:

- The Setup ("F") menu, which configures the indicator to your weigh platform
- The User ("A") menu, which configures the serial communication port and enables some user options

Both menus consist of several menu selections, each with its own sub-menu of selections or programming procedures. To configure the indicator you must first enter the appropriate menu mode. Once there, four of the front panel keys become directional navigators to move around in the menus, and one key is used to save or SET the selections.


ACCESSING THE MENUS

To access the Setup ("F") menu:

1. Power off the indicator by pressing and hold the ZERO/OFF key.
2. Locate the slide switch on the rear cover and move it to the opposite position.
NOTE: A metal plate held on by two drilled-head screws may conceal the slide switch.
3. Power on the indicator.
The display shows " F 1" to indicate that you are in Setup Menu mode.
4. Use the navigation keys shown in the Figure 10 to move through the menu.

To access the User ("A") menu:


1. Enter the Setup ("F") menu.
2. Use the right or left directional keys shown below to move right or left in the Setup ("F") menu until the indicator shows " A 1".



MENU STRUCTURE

All menus consist of a top level (heading) and a secondary level. The top level contains the code (e.g. F1) for the parameter to be configured. The secondary level contains the selection list or allows access to a programming sequence.

Use the directional keys to move around in the Menu Structure shown below.



1. To move to a new heading, use the TARE (left) or ON/PRINT (right) key to move right or left in the Menu.
2. To move to the selection or programming level, press the ZERO/OFF (down) key once. The currently saved selection is shown.
3. To view the available selections for the current heading, use the TARE (left) or ON/PRINT (right) key to move through the selection field.
4. To save a new selection, press the NET/GROSS (Set) key .To exit without saving, press the UNITS (up) key to return to the current heading.
5. Repeat Steps 2 through 5 until the Menu is programmed.

SETUP MENU DESCRIPTIONS

This section provides more detailed descriptions of the selections found in the Setup Menu Chart. Factory-set defaults are shown in bold with a checkmark.

NOTE: Some selections are subject to local legal metrology regulations

CODE/NAME	DESCRIPTION	SELECTION LIST
F1 Graduations	Specifies number of full-scale graduations, i.e. capacity / division. Value should be consistent with legal regulations and environmental limits on the useful system resolution.	500 1,000 1,500 2,000 2,500 3,000 4,000 5,000 √ 6,000 8,000 10,000 12,000 20,000 30,000 40,000 50,000
F2 Sampling Rate	Selects the sampling rate of the indicator. Selections are in samples per second (Hz).	10 √ 80
F3 Zero Track Band	Selects the range within which the scale will automatically zero. Note that the scale must be in standstill to automatically zero. Selections are in display divisions (d).	0 0.5 √ 1 3 5
F4 Zero Range	Selects the range (expressed as a percentage of full scale capacity) within which the scale may be zeroed. Note that the indicator must be in standstill to zero the scale.	100% √ 1.9% 2% 20%
F5 Motion Band	Sets the level at which motion is detected. If motion is not detected, the scale can process a Print or Zero command. Maximum value varies depending on local regulations. Expressed as scale divisions per second (d/s).	0.25 1 √ 3 5 10 15 20 30 40 50
F6 Digital Filter	Averages weight readings to produce higher stability. The higher the setting, the greater the accuracy but the slower the response time. Choose the speed that works best for your application.	1 2 4 8 √ 16 32 62 128

CODE/NAME	DESCRIPTION	SELECTION LIST
F7 Overload Limit	Selects the desired formula which determines the point at which the indicator shows overload. All selections are based on the primary unit selected in F8. "FS" = Full scale capacity.	FS FS + 2% √ FS + 1d FS + 9d
F8 Calib. Unit	Selects the primary base unit to be used in the calibration process. Also the default unit for normal operation. "1" = primary unit is lb. "2" = primary unit is in kg.	1 √ 2
F9 Display Divisions	Determines the desired weight increments. Value should be consistent with legal requirements.	1 √ 2 5
F10 Decimal Pt.	Determines location of the decimal point.	0 √ 0.0 0.00 0.000 0.0000 00
F11 Initial Zero Setting Mechanism (IZSM)	Selects the range (expressed as a percentage of full scale capacity) within which the scale automatically zeroes upon power-up (initialization).	0% 2% 10% 20% 100% √
F12 Percentage Hold ¹	Allows you to select the percentage (of the displayed held value) of weight change before the scale automatically unlocks the held reading and re-locks onto the new weight.	5% 10% √ 20% 50% 75% 100%
F16 Zero Calibration	Places indicator into the zero calibration routine. Scrolling down with the ZERO/OFF key one level begins the procedure.	Press ZERO/OFF key to begin sequence
F17 Span Calibration	Places indicator into the span calibration routine. Scrolling down with the ZERO/OFF key one level begins the procedure.	Press ZERO/OFF key to begin sequence
F18 View Calibration	Actuates the function that allows you to view both the zero and span calibration value. The values displayed in this function are valid only after Calibration (F16 & F17) has been successfully completed. Scrolling down with the ZERO/OFF key one level begins the procedure.	Press ZERO/OFF key to begin sequence
F19 Key-in Zero	Allows you to key-in known zero calibration value in case of memory loss in the field. Scrolling down with the ZERO/OFF key one level begins the procedure.	Press ZERO/OFF key to begin sequence
F20 Key-in Span	Allows you to key-in a known span calibration value in case of memory loss in the field. Scrolling down with the ZERO/OFF key one level begins the procedure.	Press ZERO/OFF key to begin sequence
F21 Factory Reset	This sub-menu will reset all parameters in the "F" and "A" menu to the default settings. USE WITH CAUTION!	Press the ZERO/OFF key twice to execute.

¹ Note this menu will not appear on older units

USER MENU DESCRIPTIONS

This section provides more detailed descriptions of the selections found in the User Menu Chart. Factory-set defaults are shown in bold with a checkmark.

NAME/CODE	DESCRIPTION	CODE/VALUE
A1 Baud Rate	Selects the baud rate for data transmission through the serial port.	1200 2400 4800 9600 ✓ 19200
A2 Data Bits and Parity	Selects the number of data bits and parity of serial transmission. "8n" = 8 data bits with no parity bit and one stop bit "7O" = 7 data bits with odd parity bit and one stop bit "7E" = 7 data bits with even parity bit and one stop bit "7n" = 7 data bits with no parity bit and two stop bits	8n ✓ 7O 7E 7n
A3 Mode of Serial Transmission	Selects when data will be sent out of the serial port to a printer or computer: "C" = Continuous mode; send data continuously "d" = Demand mode; send data when a PRINT command is issued from the printer, computer, or indicator.	C d ✓
A4 Display Check	Actuates the function that illuminates all digit segments, decimal points, and LCD annunciators in a test sequence. Pressing the ZERO/OFF key to scroll down one level begins the test sequence.	Press ZERO/OFF key to begin sequence
A5 Disable the lb/kg Key	Allows the lb/kg key to be disabled so that an operator cannot accidentally press the key and change the displayed units. "0" = Disable the lb/kg key "1" = Enable the lb/kg key	0 1 ✓
A6 Serial Port Mode	Selects the mode of the RS-232 serial port: Refer to Appendix B for more information. "0" = Full Duplex Mode "1" = Print Ticket Mode	0 1 ✓
A7 ID No. Enable	Allows the ID number to be disabled in the Print Ticket mode. Valid only when A6 is set to "1". "0" = Disable the ID No. "1" = Enable the ID No.	0 ✓ 1
A8 ID No. Entry	Actuates the function that allows entry of a new ID No. Valid only when A6 is set to "1". Pressing the ZERO/OFF key to scroll down one level begins the sequence.	0 – 999999 123456 ✓
A9 No. of Line Feeds	Actuates the function that allows entry of the desired number of line feeds to be printed in Print Ticket Mode. Valid only when A6 is set to "1". Pressing the ZERO/OFF key to scroll down one level begins the sequence.	0 - 99 8 ✓
A10 Auto Power Off Period	Selects the automatic power off time in minutes –indicator must be inactive during this period in order to shut off. "Off" = function disabled (indicator always stays on)	Off 1, 2, 3, 5 ✓, 8 10, 15, 20, 30

NAME/CODE	DESCRIPTION	CODE/VALUE
A11 Hold Mode	<p>This mode captures the weight of an unstable load, e.g. livestock, by freezing the weight on the display. Use the Motion Band setting (F5) and the Percentage Hold setting (F12) to adjust this mode to your specific application. When the weight has been locked onto the display, two arrows beneath the weight display will be turned ON.</p> <p>"0" = Off</p> <p>AUTOMATIC (A11 = 1) – Automatically locks weight on the display when stable. If the weight of the object on the scale changes by the F12 setting (e.g. 10%) then the sale unlocks the held reading and relocks onto the new weight. This occurs during both increasing and decreasing weight values.</p> <p>MANUAL (A11 = 2) – Press the NET/GROSS key <u>before</u> applying any weight to the scale. After the load has stabilized, the display will hold the weight reading on the screen until the NET/GROSS key is pressed again. If the weight of the object on the scale changes by the F12 setting (e.g. 10%) then the sale unlocks the held reading and relocks onto the new weight. This occurs during increasing weight values only.</p> <p>PEAK HOLD (A11 = 3) – The display updates as the load increases but not as the load decreases. The value shown on the screen is the maximum weight applied to the scale. Press the UNITS key to toggle between live mode and peak hold mode. The 'P' annunciator is used to indicate that you are in Peak Hold mode. When you exit out of peak hold mode, the old peak value is automatically cleared.</p> <p>SEMI-AUTOMATIC (A11 = 4) – Same as Automatic mode except that you can use the NET/GROSS key to cancel; press the NET/GROSS key again to re-arm.</p>	0√ 1 2 3 4
A12 Handshaking Enable	<p>Enables hardware handshaking for Print Ticket Mode. Valid only when A6 is set to "1".</p> <p>"0" = Disable Handshaking "1" = Enable Handshaking</p>	0√ 1
A13 Print Header	<p>Tells MP-20 printer to print the header information. Valid only when A6 is set to "1".</p> <p>"0" = Do NOT Print Header "1" = Print Header</p>	0√ 1
A14 Min. Hold Wt	<p>When automatic hold mode (A11=1) is enabled, sets the minimum weight that can be held; expressed in scale divisions ("d").</p>	1, 2, 5√ , 10, 20 50, 100, 200, 500, 1000

NOTE: on older units, this menu item will look like this instead:

A11 Automatic Hold Mode	<p>Activates automatic hold mode in which the weight of the object on the platform is frozen until the weight is decreased to one-half of the held weight. Useful for animal weighing.</p> <p>"0" = Disable auto hold. "1" = Enable auto hold</p>	0√ 1
-----------------------------------	--	----------------

USER MENU PROCEDURES

This section provides instructions for all of the User Menu procedures.

ID Number Entry (A8)

1. While in the User Menu mode, scroll to "**A 8**", and then scroll down once using the ZERO/OFF key to enter the ID Number menu.
2. The display will momentarily show "**ID NO**", followed by a value with one flashing digit. This value will be the current ID number value.
3. Use the four directional keys (shown below) to adjust the displayed value to the actual ID Number value. Increase the flashing digit by pressing the UNITS key. Decrease the flashing digit by pressing the ZERO/OFF key. Pressing the ON/PRINT key or the TARE key will change the position of the flashing digit.



4. After setting the exact value, press the NET/GROSS key to save the ID Number value. The display will show "**SET**" momentarily, and then revert back up to A8.

LF (Line Feeds) Number Entry (A9)

1. While in the User Menu mode, scroll to "**A 9**", and then scroll down once using the ZERO key to enter the Line Feeds menu.
2. The display will momentarily show "**LF**", followed by the current line feeds value.
3. Use the four directional keys (shown below) to adjust the displayed value to the actual ID Number value. Increase the flashing digit by pressing the UNITS key. Decrease the flashing digit by pressing the ZERO/OFF key. Pressing the ON/PRINT key or the TARE key will change the position of the flashing digit.
4. After setting the exact value, press the NET/GROSS key to save the line feeds value. The display will show "**SET**" momentarily, and then revert back up to A9.

EXITING THE MENUS

Exit any configuration menu by moving the slide switch to its original position. The display will go through a digit check, and then settle into Normal Operating mode. All front panel keys will now return to their normal mode of operation.

CALIBRATION

CALIBRATION OVERVIEW

If your indicator was shipped as a complete scale, then calibration is not necessary. Please check with your installer or supplier if you are unsure. Transcell recommends having your weighing equipment checked by a qualified scale technician at least once a year depending on its intended use and working environment.

The indicator requires two types of calibration: zero and span. Zero calibration (F16) requires the scale to be empty (nothing on scale) and the span calibration (F17) requires known test weights. After a successful calibration, you should record all calibration values in Table 2 using the F18 View Calibration procedure.

In the unlikely event that any calibration value is lost, the setup menu makes provisions for re-entering these values via F19 and F20; thus eliminating the need for re-calibration with test weights.

NOTE: This section assumes that the indicator is in Setup ("F") Menu mode. If the indicator is not in Setup Menu mode, refer to previous section for instructions.

ZERO CALIBRATION (F16)

1. While in the Setup mode, scroll to "**F 16**", and then scroll down once using the ZERO/OFF key to enter zero calibration menu. The display will momentarily show "**C 0**" followed by a value. This value is the internal A/D count and can prove useful when trying to troubleshoot setup problems.
2. After making sure that there are no test weights on the platform, press the ZERO key to zero out the displayed value.
3. Press the NET/GROSS key to save the zero point value. The display will show "**EndC0**" momentarily, and then revert back up to F16. At this time, proceed to the F17 span calibration to complete indicator calibration.

SPAN CALIBRATION (F17)

1. While in the Setup mode, scroll to "**F 17**", then scroll down once using the ZERO/OFF key to enter span calibration menu. The display will momentarily show "**C 1**" for the span calibration point, followed by a value with one flashing digit. This value will be zero with the Decimal Point parameter selected in F10.
2. Place the test weight on the weighing platform.
3. Use the four directional keys to adjust the displayed value to the actual test weight value. Increase the flashing digit by pressing the #1 key. Decrease the flashing digit by pressing the ZERO/OFF key. Pressing the #4 key or the #5 key will change the position of the flashing digit.
4. After entering the exact value, press the NET/GROSS key to save the value. If the calibration was successful, the display will show "**EndC1**" momentarily, and then revert back up to F17
5. At this time it is suggested that the calibration values be recorded for future use (see next section).

If the calibration was *not* successful, one of the error messages below will appear. Take the indicated action to correct the problem, and then perform a new calibration.

"Err0" - The calibration test weight or the keyed-in weight is larger than the full capacity of the scale. Change the calibration test weight or check the input data.

"Err1" - The calibration test weight or the keyed-in weight is smaller than 1% of the full capacity of the scale. Change the calibration test weight or check the input data.

"Err2" – There is not enough signal from the load cells to establish a proper calibration. Most common causes include incorrect load cell wiring, a mechanical obstruction or a faulty (damaged) load cell.

VIEW CALIBRATION VALUES (F18)

Note: The values displayed in this procedure are valid only after a successful calibration has been performed using F16 and F17.

1. While in the Setup mode, scroll to "F 18", then scroll down once using the ZERO/OFF key to enter View calibration menu.
2. The display will show the information listed in Table 2. The code will display briefly followed by the value. It is recommended that you record each value in the table below. Press any key to continue down the list. At the completion of the list, the indicator reverts back up to F18.

ZERO CALIBRATION VALUE (C0)	SPAN CALIBRATION VALUE (C1)

Table 2: Calibration Value Table

KEY-IN ZERO CALIBRATION VALUE (F19)

Note: This procedure is intended for emergency use only in the case of non-volatile memory loss. A valid zero calibration value, obtained from a successful F16 calibration procedure, must be used.

1. While in the Setup mode, scroll to "F 19", and then scroll down once using the ZERO/OFF key. The display will momentarily show "CAL 0", followed by a value of zero
2. Use the four directional keys to enter in the actual zero calibration value.
3. After entering the exact value, press the NET/GROSS key to save the value. The display will show "E CAL 0" momentarily, and then revert back up to F19.

KEY-IN SPAN CALIBRATION VALUE (F20)


Note: This procedure is intended for emergency use only in the case of non-volatile memory loss. Valid span calibration values, obtained from a successful F17 calibration procedure, must be used.

1. While in the Setup mode, scroll to "F 20", and then scroll down once using the ZERO/OFF key. The indicator will prompt you to enter the CAL 1 span calibration data from Table 2.
2. Use the four directional keys to enter in the actual calibration value
3. After setting the exact value, press the NET/GROSS key to save the value.
4. If the entered values are entered successfully, the display will show "E CAL 1" momentarily before reverting back up to F20.

OPERATION

DISPLAY

This model utilizes a 6-digit LCD (Liquid Crystal Display). Table 3 summarizes the display annunciators.



LCD Annunciator	MEANING
→0←	Displays when the scale is center of zero.
N	Indicates that the indicator is displaying net weight (Gross weight minus Tare weigh).
G	Indicates that the indicator is displaying gross weight
T	Indicates that a push-button TARE weight has been established in the system.
P	Indicates that the indicator is in PEAK HOLD mode
lb, kg	Indicates the unit of the displayed weight. (lb = pounds, kg = kilograms)
▲ ▲	This light is on whenever the scale is at rest (stable reading).
▼ ▼	When the displayed weight is 'locked on', these two annunciators will be lit.

TABLE 3: TI-500-SL Annunciator Definitions

KEYBOARD

The keyboard is composed of fourteen function keys shown below.



FUNCTION KEYS

Units – This key toggles the indicator among the available weight units if enabled in the User (“A”) menu. Available weight units include lb and kg.

Zero/Off - This key sets the indicator to display zero provided the following conditions are met:

1. The indicator is displaying Gross weight.
2. The displayed weight is within the zero reset range that is programmed in F4 of the Setup (“F”) Menu.
3. The scale is not in motion.
4. The scale is not in overload (see Appendix D for error codes).

When held for five seconds, shuts the unit off.

Net/Gross - This key toggles the indicator between Gross weight and Net weight only if a Tare has been established.

Tare - This key is used to establish a Tare provided the following conditions are met:

1. The indicator is not at or below Gross zero.
2. The scale is not in motion.
3. The scale is not in overload (see Appendix D for error codes).

On/Print – When the unit is off, turns the unit on. When the unit is on, this key is used to send weight information out to the serial port provided the following conditions are met:

1. The scale is not in motion.
2. The scale is not in overload (see Appendix D for error codes).

GENERAL SCALE OPERATION

WEIGHING AN ITEM

1. Select the desired weighing unit by pressing the UNITS key until that unit is indicated on the display.
2. If necessary, press the ZERO/OFF key to obtain a weight reading of zero.
3. If weighing an item in a container, place the empty container on the scale’s platter and, after allowing the weight indication to stabilize, press the TARE key. The display shows zero weight and turns the NET annunciator on
4. Place the object to be weighed on the scale’s platter and allow the weight indication to stabilize. If the item weight exceeds the scale’s weight capacity, it displays “000000”.
5. Read the weight shown on the display. If you have established a tare, you may toggle between the gross weight and the net weight by pressing the NET/GROSS key

WEIGHING ANIMALS

This mode of operation is enabled by setting F30 to “5” in the Setup Menu (see separate installer’s guide for more information). This mode captures the weight of an unstable load, e.g. livestock, by freezing the weight on the display. Use the Motion Band setting (F5) and the Percentage Hold setting (F12) to adjust this mode to your specific application. When the weight has been locked onto the display, two arrows beneath the weight display will be turned ON.

There are several specific hold modes, which are selected thru the A11 setting.

AUTOMATIC (A11 = 1) – Automatically locks weight on the display when stable. If the weight of the object on the scale changes by the F12 setting (e.g. 10%) then the scale unlocks the held reading and relocks onto the new weight. This occurs during both increasing and decreasing weight values.

MANUAL (A11 = 2) – Press the NET/GROSS key before applying any weight to the scale. After the load has stabilized, the display will hold the weight reading on the screen until the NET/GROSS key is pressed again. If the weight of the object on the scale changes by the F12 setting (e.g. 10%) then the scale unlocks the held reading and relocks onto the new weight. This occurs during increasing weight values only.

PEAK HOLD (A11 = 3) – The display updates as the load increases but not as the load decreases. The value shown on the screen is the maximum weight applied to the scale. Press the UNITS key to toggle between live mode and peak hold mode. The 'P' annunciator is used to indicate that you are in Peak Hold mode. When you exit out of peak hold mode, the old peak value is automatically cleared.

SEMI-AUTOMATIC (A11 = 4) – Same as Automatic mode except that you can use the NET/GROSS key to cancel; press the NET/GROSS key again to re-arm.

RECHARGEABLE BATTERY INFORMATION

OVERVIEW

Your scale contains an internal lead-acid rechargeable battery. Before using the indicator for the first time, please charge the battery overnight.

The indicator's battery should operate for about 40 hours if connected to a four load cell platform and left on continuously. Greater usage times can be achieved by selecting an appropriate Auto Power Off Period under **A10** of the User Menu.

The battery can be charged while ON or OFF and the indicator can be operated while it's charging unless the state of charge is very low.

WHEN TO CHARGE THE INTERNAL BATTERY

The best time to charge the sealed lead-acid type battery is any time the indicator is not in use. You need not wait for the Low Battery Indication – in fact it's best that you don't. Charging the battery when not in use keeps the battery "fresh" and is the recommended way to manage it.

When the battery needs to be charged, the Low Battery Indicator will slowly flash in the upper left-hand corner of the display. The indicator may be used for an additional 10 minutes without damage to the internal battery. Halfway thru this time, the Low Battery Indicator will start to flash quickly. Eventually, the indicator will display "bAtt" for 2-3 seconds and then automatically power down. ***It is imperative that you charge the battery at this time to avoid damage.***

HOW TO CHARGE THE INTERNAL BATTERY

1. Connect the charger (AC Adapter 12 VDC, 800mA) to the scale, and then plug the charger into an AC outlet. ***Make sure that the AC voltage appearing at the wall outlet matches the input voltage marked on the AC adapter.***
2. After the charging period expires, unplug the charger from the AC outlet, then from the scale. The scale is now ready for use under its own battery power.

NOTE: The charger may be left connected to the scale indefinitely without damage to the internal battery.

HOW LONG TO CHARGE THE INTERNAL BATTERY

In general, the battery should be allowed to charge a minimum of 1.5 hours for every hour of use. If you discharge the battery below 50% and do not allow the proper time for charging, you may start to notice a decline in the usage period. This is normal and eventually the battery must be replaced.

REPLACING THE BATTERY

The recommended practice when removing the battery is to disconnect the ground connection (black) first, then the red terminal. This ensures that a short circuit will not occur from a battery lead or fuse lead touching the grounded housing while disconnecting the other terminal. Similarly, the ground should be connected last when installing a new battery.

The US government has classified the internal battery as hazardous waste. Do not place battery into landfill. An automotive store or a local waste agency may accept the batteries for recycling. Contact the manufacturer for more information.

LEGAL FOR TRADE SEALING

Indicators can be sealed for commercial (Legal for Trade) applications as follows.

1. Power off the indicator.
2. On the back of the indicator, locate the setup/calibration switch cover.
3. Thread a wire security seal through both drilled head screws securing the calibration switch cover as well as the single drilled head screw holding on the rear panel.



APPENDIX A: SPECIFICATIONS

ANALOG SPECIFICATIONS

Full Scale Input Signal	±3.125 mV/V
Minimum Sensitivity - Non trade	0.3 µV / grad
Minimum Sensitivity - H-44	0.6 µV / grad
Input Impedance	30MΩ, typical
Internal Resolution	Approximately 280,000 counts @ 2mV/V input
Display Resolution	50,000 display division max
Measurement Rate	10 Hz/80 Hz selectable
System Linearity	Within 0.02% of FS
Calibration Method	Software Calibration, with long term storage in EEPROM
Excitation Voltage	+4.7 VDC, 4 x 350Ω load cells

DIGITAL SPECIFICATIONS

Microcontrollers	Winbond W78E516
Program Memory	64K x 8, internal to µC
SRAM:	512 x 8, internal to µC
EEPROM:	256 x 8, external to µC
Digital Filtering	Software selectable

SERIAL COMMUNICATIONS

Serial Port	Full Duplex, selectable Baud rate
	8 data bits, no parity, 1 stop bit
	7 data bits, odd parity, 1 stop bit
	7 data bits, even parity, 1 stop bit
	7 data bits, no parity, 2 stop bits

OPERATOR INTERFACE

Display	0.8" (20 mm) 7-segment, LCD, 6 Digit
Additional Symbols	Net, Gross, Stable, Tare, lb, kg, Zero, Low battery
Keyboard	5-key flat membrane panel

POWER

AC Adapter	12 VDC
Rechargeable Battery	6 V, 3Ah lead-acid
DC Power Consumption	70mA + 13mA/350Ω Load Cell

ENVIRONMENTAL

Operating Temperature	-10° to +40 ° C
Storage Temperature	-25° to +70 ° C

MECHANICAL

Overall Dimensions (L x W x H)	9.0" x 5.5" x 2.9" (231mm x 140mm x 72mm)
--------------------------------	---

APPROVALS

NTEP	COC # 94-080A3
Measurement Canada	AM-5800C
FCC	FCC Part 15: Subpart B

APPENDIX B: SERIAL PORT INFORMATION

SERIAL PORT MODES

DEMAND DUPLEX MODE

The Demand Duplex Mode (A3 = 'd', A6 = '0') provides a two way serial transmission mode. In this mode, the output information is transmitted on demand; either by pressing the PRINT key on the indicator's front panel or upon receiving a recognized command from a host device (i.e. computer).

NOTE: Ensure that your cabling contains the proper handshaking.

CONTINUOUS DUPLEX MODE

The Continuous Duplex Mode (A3 = 'C', A6 = '0') provides a two-way serial transmission mode. In this mode, the output information is transmitted continuously making it a popular choice for remote displays and other remote devices requiring a constant data stream. The transmission automatically occurs at the end of each display update. The indicator will react upon receiving a recognized command from a host device.

RECOGNIZED HOST COMMANDS (applies to both demand and continuous duplex modes)

- "P"** - This command is sent to the indicator to print the indicated display. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- "Z"** - This command is sent to the indicator to zero the scale. The indicator will not respond if the scale is in motion, positive overload or negative overload. The indicator will also not respond if it is not in gross mode or within the zero range specified in F4 of the Setup Menu.
- "T"** - This command is sent to the indicator to tare the scale. The indicator will not respond if the scale is in motion, positive overload or negative overload. The indicator will also not respond if it is displaying a negative gross value.
- "G"** - This command is sent to the indicator to switch to gross mode. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- "N"** - This command is sent to the indicator to revert to net. The indicator will not respond if the scale is in motion, positive overload or negative overload. The indicator will also not respond if a tare has yet to be established.
- "C"** - This command is sent to the indicator to toggle among the configured units of measure.

OUTPUT STRINGS

TEXT PRINT TICKET

The Text Print Ticket is designed specifically for a serial printer. Ensure that A6 is set to '1'. For printers with limited buffers, this mode supports DTR pin handshaking. The DTR pin from the serial printer is wired to the indicator's RXD pin which then functions as a CTS pin. Refer to the printer's user manual to confirm which pin is the DTR pin.


ID. NO.	123456
GROSS	25.00 LB
TARE	1.48 LB
NET	23.52 LB

NOTES:

1. The TARE and NET fields are not printed unless a tare has been established in the system.
2. The ID number field is not printed if it is disabled in A7 of the User Menu.


STRING FORMAT 1 (Condec Demand String)

String Format 1 is designed for two-way communication. Ensure that A3 is set to 'd' and A6 is set to '0'.



STRING FORMAT 2 (Condec Continuous String)

String Format 1 is designed for one-way communication. Ensure that A3 is set to 'C' and A6 is set to '0'.



APPENDIX C: DISPLAYED ERROR CODES

CODE	MODE	MEANING / POSSIBLE SOLUTION
	Normal Operating Mode	Gross Overload. A weight greater than the rated capacity has been applied to the scale. Remove the weight from the platter or try re-calibrating the scale. Otherwise, check for a bad load cell connection or possible load cell damage due to overloading.
Err 0	Span Calibration Mode (F17)	Keyed-in weight value is larger than full-scale capacity. Use a smaller test weight or check keyed-in value.
Err 1	Span Calibration Mode (F17)	Keyed-in weight value is less than 1% of full-scale capacity. Use a larger test weight or check keyed-in value.
Err 2	Span Calibration Mode (F17)	There is not enough load cell signal to produce the internal counts necessary to properly calibrate the scale. First check all load connections. Use F16 mode to view internal counts.
Err 3	All Modes	Non-volatile memory read error. One or more setup parameters have been lost.
Err 4	All Modes	Non-volatile memory write error. Indicator needs service.
Err 5	Key-in Span Calibration Mode (F20)	You have attempted to enter a zero value for C1. Enter a known calibration value greater than zero.
Err 7	Initialization	No reading from A/D converter. Check load cell connections. Check for faulty load cell.
Err 9	Normal Operating Mode	Span calibration value has been lost. Re-calibrate the scale.
	Normal Operating Mode	When blinking slowly, indicates that battery life has reached its useful end and <u>needs to be recharged</u> soon. When blinking quickly, indicates that the unit will soon power down indeterminately
Flashes "bAtt"	Normal Operating Mode	Indicates that the unit must power down automatically within 2-3 seconds in order to help prevent damage to the internal rechargeable battery