



# TRANSCCELL TECHNOLOGY, INC.

## MP-20 Printer Header Software

1. Connect the printer cable to the printer and a COM port on your computer
2. Start the header software
3. Click the appropriate COM port and click OK
4. An opening screen appears and displays the current header settings.

5. Click a desired field to change and Click modify to change. Enter the text and select font and alignment by clicking on the down arrow in each field. Click apply and OK to save and transmit the changes to the printer. Use the test print option to view the changes on the printer. Repeat for each field.

